

?

????????? ?????????????????? ??????? (UPS, ??? 103006721-6591) Eaton 9135 5000



5000??, 3500??, 3U,

????????: ??? ???????
????:

[???????? ??????? ?? ????? ???????](#)

?????????????: [EATON](#)

?????????

????????????????

???????????????? : Eaton

??? : ? ??????? ??????????????????

?????????, ??? : 5

???? : ??????

?????/?????? : ????: ??????? ??????? ??????: ??????? ??????? + C19(2),C13(8)

????????? : COM (RS-232), USB

???. ??????????? ??????????? (AVR) : ??

?????? ?? ?????????? ??????????? : ????

?????????

??? ??? ? ??????? ?????????????????? ???????????

?????????

5000 ??

???? ??????

?????/?????? ????: ??????? ???????

?????: ??????? ??????? + C19(2),C13(8)

????????? COM (RS-232), USB

???. ??????????? ??????????? (AVR) ??

????? ?? ?????????? ?????????? ????

????????????????? ?????????? ??????: Tower / Rack 3U

????????? ?????????? ??????????: 156 - 280 ?.

???? ??? ?????????????????? ?????: ConnectUPS-MS NMC (103006826)

????????? ?????????????????? ?????? ? ?????????? ?????? ??? ?????????? 75% ? 50%: 8/13 ???.

??? ?????????? 75% ? 50%: +1EBM, +2EBM, +3EBM, +4EBM 33/50, 62/91, 93/134, 124/177

????????????????? ?????????? ??? EBM: ?? . ????? (103006723-6591)

????????? (?????): 444 ? 130 ? 741 ??.

??? : 57 ??.

?????????: 12 ???.

??????

??? ???????? ?? ??? ??????.